

HUSH-CRADLE Adjustable Resilient Flooring Cradles

General

For Hush-Cradles

Should you have any technical questions prior to or during installation, please call 0151 933 2026 for friendly and straightforward advice.

Sound insulation systems should be installed independently within each room.

To avoid plaster cracks and for good acoustic practice partition walls should only be built up from the structural base and not the floating floor. For ease of installation all structural bases should be level. Grout all joints, fill any gaps and thoroughly sweep the area before proceeding. If there is any likelihood of damp always lay a damp proof membrane over the structural slab.

Cradle Installation

Always ensure cradles are correctly threaded before laying.

Set out the cradles at the required centres, usually up to 450mm for 18mm flooring or a maximum of 600mm for 22mm flooring. Install the timber battens and try to have joins directly over a cradle or use double cradles. Allow for perimeter cradles / timber battens at the end of the batten runs. All perimeter cradles / battens must be isolated by at least 25mm from the walls.

Levelling

Levelling is carried out by adjusting the nylon carriers up and down the threads, as required, to achieve a consistently level floor.

Lock by turning the carrier up stands against the battens.

Fitting the Flooring

When planning the floor layout leave a 10-15mm gap around all perimeters (except for Robust Details– see below).

Fix the flooring to the battens using a generous amount of Hush-Bond Panel Adhesive and secure with ring nails or screws. At the same time the flooring boards should be glued at all teegee joints board to board. Neatly press Hush-Seal 20 Perimeter Seal into the 10-15mm gap that has been left around all perimeters, creating an airtight seal.

Always try to avoid walking on the floor surface until all glue has cured.

Skirting should be fitted a minimum of three millimeters clear of the floor surface. (PCT only).

Robust Details

When using Hush-Cradle for Robust Details projects the perimeter of the floor must be isolated from the walls with Hush-RD Flanking Strip. The strip is turned over the surface of the flooring and the skirting is fitted neatly on top of the strip prior to trimming with a sharp blade.

Technical Advice

For advice on the specification or use of Hush-Cradles within any project, please contact our experienced technical team on **0151 933 2026** who will be happy to give comprehensive and practical advice to meet with your requirements.

HUSH (UK) LIMITED
44 Canal Street, South Sefton, Merseyside, L20 8QU
T: 0151 933 2026 F: 0151 944 1146 E: info@hush.uk.com W: www.hush.uk.com